


HOLATRON

OPERATION & MAINTENANCE GUIDE - Single Output UHF Micro-receiver, CH 1/2



HOLATRON SYSTEMS, LLC

833 ILANIWAI ST, STE. 2

HONOLULU, HI 96813

(808) 372-0956

www.holatron.com

WARNING

Holatron Systems specializes in the design and manufacture of standard and custom electronic control systems where reliability and error free data communication are critical. The receiver described in this manual is part of a system intended to remotely actuate pyrotechnic or other hazardous devices, and the components of this system have been carefully designed to minimize the possibility of accidental actuation of such devices. Holatron's design goal is to ensure that data communication errors due to radio interference or to insufficient signal strength due to low battery, exceeding specified range, or conductive objects in the signal path will result in failure of intentional actuation rather than unintended actuation. Techniques used to achieve this design goal are described in section 2.0. Though the probability of unintended actuation is extremely small, it cannot be guaranteed to be zero. Therefore, **it is important that the user not arm the receiver until all persons who might be harmed by accidental actuation are in a safe area.**

As a condition of purchase, the user must acknowledge awareness and agreement that utilization of this product and participation in activities utilizing fireworks, rockets, and explosives is an ultra-hazardous activity carrying implied and explicit risks of injuries and damages to the user and to other participants. The user assumes the risk connected with the utilization of this product and all risks of participation in the activities for which this product is sold. User acknowledges that he/she/it has the necessary and required skill, expertise, training and licensing, as may be applicable or necessary by custom, usage, trade or law, to engage and participate in the ultra-hazardous activities connected with the use, purchase, transportation, or employment of the products sold under this agreement. User acknowledges that Holatron Systems, LLC, has not and will not conduct any investigation into the skill, expertise, training and licensing, as may be applicable or necessary by custom, usage, trade or law, of the user or of user's agents, employees and assigns, to engage and participate in the ultra-hazardous activities connected with the use, purchase, transportation, or employment of this product. User specifically agrees that Holatron Systems, LLC, its officers, employees, and agents shall not be liable for any claim, demand, cause of action of any kind whatsoever for, or on account of death, personal injury, property damage or loss of any kind resulting from or related to user's or user's employees', agents' or assigns' use of this product, and user agrees to indemnify, defend in any action at law, and hold harmless Holatron Systems, LLC, from same, whether brought by the user, user's agent, or assigns, or any third party.

This manual is divided into four sections. The first is a description of the system hardware. The second describes radio interference suppression methods. The third lists transmitter specifications. The fourth covers the recommended operating and maintenance procedure.

1.0 HARDWARE DESCRIPTION.

The model RFLS-P91HSRC micro-miniature single output multi-mode UHF receiver is a highly sensitive narrow band (superhetrodyne) digital radio receiver with internal antenna designed to be used for medium range remote control applications where high reliability is critical. When used with the Holatron model RFLS-6HSXT, RFLS-6HSXTX, RFLS-12XT or RFLS-12XTX remote control transmitters, a range of ¼ mile (line of sight operation) is typical, provided there are no intervening conductive objects. Range increases as the receiver is elevated above earth or other conductive objects.

The reception carrier frequency is fixed at 418 MHz by a SAW (surface acoustic wave) oscillator for exceptional stability. No alignment or tuning procedures are ever required to maintain optimum performance.

The receiver's firing signal is digitally decoded from the transmitted digital code which is amplitude modulated on a single carrier frequency of 418 MHz. This receiver is compatible with the Holatron model RFLS-6HSXT or RFLS-6HSXTX high speed sequential transmitters and with the RFLS-12XT or RFLS-12XTX random 12/72-shot transmitters.

The transmitted digital codes from the RFLS-6HSXT & RFLS-6HSXTX indicate to the receiver which of the two transmit buttons, "A" or "B", is being pressed. The "A" button fires the show cues sequentially. (Each depression of the button fires the next show cue in sequence.), and "B" button commands fire show cues in fully automatic mode as explained in the transmitter manual.

The transmitted digital code from the model RFLS-12XT indicates to the receiver which of its 12 random-fire buttons is being pressed and causes that cue to be fired immediately. The "Next Fire" button transmits a digital code that causes the next cue in sequence to be fired. After pressing the Rst button, the next depression of The "Next Fire" button will fire cue 1. This transmitter can fire a maximum of 12 cues with these receivers.

Pressing the Rst button on the model RFLS-12XTX causes the transmitter to switch to the channel indicated by the following press of one of the numeric keys (1 – 6). This allows manual selection of the communications channel. See the transmitter manual for a detailed description of channel selection.

There are six different communication channels available. Each channel is designated by a numeral (1 through 6). The transmitter will control receivers set to the channel matching that being used by the transmitter. Receiver channel number and output cue numbers are selected by the receiver digital switch setting as shown in the following tables.

Transmitters that are set to separate channels can transmit simultaneously to separate receivers without interfering with each other, permitting up to six separate receivers or groups of receivers to be controlled by six separate transmitters simultaneously. Transmitters set to the same channel will interfere with each other and possibly result in failure-to-fire at the corresponding receivers. Note that transmitters only transmit while a button is pressed.

Firing Cue Selection Table for Miniature Receiver Output:

| Rcvr Digital Switch Setting | Show Cue Selection | Channel Cue Selection | Digital Channel Selection |
|------------------------------------|---------------------------|------------------------------|----------------------------------|
| 0 | 16 | 4 | 2 |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 1 |
| 3 | 3 | 3 | 1 |
| 4 | 4 | 4 | 1 |
| 5 | 5 | 5 | 1 |
| 6 | 6 | 6 | 1 |
| 7 | 7 | 7 | 1 |
| 8 | 8 | 8 | 1 |
| 9 | 9 | 9 | 1 |
| A | 10 | 10 | 1 |
| B | 11 | 11 | 1 |
| C | 12 | 12 | 1 |
| D | 13 | 1 | 2 |
| E | 14 | 2 | 2 |
| F | 15 | 3 | 2 |

This permits multiple receivers to be used to fire multiple cues from a single transmitter. For example, two receivers set to switch positions 1 and 2, respectively, can fire 2 cues (cue 1 from the first receiver, and cue 2 from the second receiver), and 16 receivers can be used similarly to fire 16 cues. Multiple receivers can also be configured to fire simultaneously by setting their switches to the same number. Combinations of sequential and simultaneous receivers can also be used.

The Holatron transmitter being used with this receiver must be set to the channel selected by the receiver's digital mode switch. Six radio channels are available, and receivers can be ordered with custom channel assignments.

The user has access to the following components:

1.1 THE ANTENNA.

The RF signal is received by an embedded internal antenna. No external antenna is required.

Note that reception is best when the receiver is elevated at least 12" above ground level.

1.2 THE POWER & ARM SWITCHES.

These miniature slide switches are located on the circuit board. They may be optionally located remotely. The "POWER" switch turns on power to the receiver and its firing circuitry. Its "ON" position is toward the edge of the circuit board. The "ARM" switch has "Safe" and "Arm" positions. In the "Safe" position, the output leads are shunted so that the output cannot be fired. Output continuity checking is disabled in "Safe" position. **It is recommended that the receiver always be powered up in "Safe" mode if a device is already connected to the output. The operator can then verify that the STATUS INDICATOR does not indicate that any radio reception is occurring before arming the receiver.**

1.3 THE STATUS INDICATOR.

While the power switch is on and the receiver is in "Safe" mode, this indicator, located at D5 on the bottom side of the circuit board, will flash periodically in bursts of one, two, or three flashes at a time if the battery has enough capacity to power the receiver. If no flashing occurs, the battery must be replaced before the receiver can be used reliably. Three flashes per burst indicate that the battery has full capacity, two flashes indicate that its capacity is beginning to diminish, and one flash indicates that it is near the end of its useful lifetime in which case it should be replaced immediately after the current use. Adequate receiver power is available as long as the battery voltage is above approximately 1.6 volts, but the battery voltage will be dropping rapidly at this point, and receiver cutoff will occur within seconds. So the battery must be replaced immediately.

For the first minute after the receiver is armed and output continuity is detected, indicator color will be green during battery status indication. If disarmed or if the output is open, indicator color will be red.

In order to conserve battery life, the indicator light is disabled after one minute of uninterrupted green continuity indication. Switching to "Safe" mode or loss of continuity reactivates the indicator light, and the one minute timer will then restart upon switching to "ARM" mode with continuity detected.

This indicator will also light while a signal is being received that matches the expected preamble and sync code of the system communication protocol, even if it is from a transmitter set to a different cue number or digital channel. This feature is useful for warning of reception of signals before the arm switch is turned on and for indication of activity on other digital channels. A received signal that matches the receiver's cue and channel number will cause a red indication, even if the receiver is not armed. If the receiver is armed, a red signal will generate a firing output. Received signals that do not match the receiver's cue and channel number will cause a green indication.

The functionality of this indicator is summarized in the following table.

Status Indicator Function Table:

| Flash Pattern | Green | Red | Battery Level |
|----------------------------|--------------------------|---------------------------------------|----------------------|
| 3 flashes | Output connected & armed | Output open or not armed | High |
| 2 flashes | " | " | Medium |
| 1 flash | " | " | Low |
| No flashes | | | Very low, or dead |
| Continuous (1 sec or more) | Non-matching signal rcvd | Matching signal rcvd (fires if armed) | |

1.4 THE OUTPUT LEADS.

The device to be actuated should be connected to the 2 leads extending from the “+” and “-“ pads on the edge of the receiver circuit board.

Be careful that no frayed strands (whiskers) accidentally short the output leads together, as this condition will not be detected by the output continuity checker, and it will result in a failure to fire. When armed and a fire command is received that matches the receiver’s switch setting, a pulse with peak voltage of 5V is presented to the output leads. The energy in this pulse is 0.025 joules, sufficient to fire at least 2 standard e-matches in parallel or in series. The output leads are shunted when the ARM switch is in “safe” position.

1.5 THE BATTERY.

All power is supplied from one 3 volt 1/3N lithium coin type battery, contained on the receiver circuit board. Optionally, a pair of #357 silver-oxide or a pair of LR44 alkaline coin type batteries may be used, but longest life is obtained from the lithium battery.

The receiver and battery holder are not reverse polarity protected. So it is important to observe the polarity markings on the battery holder. Inserting the batteries backwards will permanently damage the receiver. Note that the shell of the battery is the positive terminal, and the projecting electrode is the negative terminal. The negative terminal of the battery holder is next to the edge of the circuit board.

The battery should be replaced when required by conditions described in section 1.3 above. In order to prevent the possibility of damage due to battery leakage, the batteries should always be removed if the receiver is to be stored for a prolonged period. Damage due to battery leakage is not covered under the warranty. The batteries can be removed from the holder by prying out gently with a miniature screwdriver.

1.6 THE DIGITAL SWITCH.

A 16 position miniature rotary switch is located at position S1 on the top side of the circuit board. It can be set to positions 0 – 9 or A – F by rotation with fingers or a small screwdriver. The receiver will only respond to a transmitter whose digital channel and transmitted cue correspond to the channel and cue selected by this switch as shown in the table in section 1.0. Multiple transmitters may be used to actuate different receivers simultaneously, even though all operate on the same frequency, if the transmitters are operating on separate digital channels and the receivers are set to those channels. **Transmitters set to the same digital channel numerals will interfere with each other and result in failure-to-fire when actuated simultaneously.**

2.0 RADIO INTERFERENCE REDUCTION.

For obvious safety reasons, Holatron's design goal is to ensure that data communication errors due to radio interference or to insufficient signal strength due to low battery, exceeding specified range, or conductive objects in the signal path will result in failure of intentional actuation rather than unintended actuation. This goal is achieved by transmitting a 64 bit noise-tolerant code repeatedly while a transmitter button is depressed. 60 of these bits must match the pattern expected by the receiver. Thus, there is one chance in (2 to the 60th power) of an actuation occurring due to reception of a random signal. Expressed in decimal numbers, this is (1.1529 times 10 to the 18th power, or 11529 followed by 14 zeroes). This is a probability of 8.6736 times 10 to the -19th power (or a decimal point followed by 18 zeroes followed by 86736). Though this probability of unintended actuation is extremely small, it cannot be guaranteed to be zero. Therefore, **it is important that the user not arm the receiver until all persons who might be harmed by accidental actuation are in a safe area.**

Additional protection is offered by use of 418 MHz as the operating frequency. This frequency is sparsely used only by low power transmitters with a maximum range of approximately 100 yards. It is not commonly used by auto security systems, garage door openers, radio control models, cordless or cellular telephones, wireless microphones, or two way communications equipment. Because this system operates in the UHF region, interference from lamp dimmers, electrical discharges, and other natural sources is also minimal.

No instances of false triggering with this communications technology have been reported to date.

3.0 SPECIFICATIONS.

| Parameter | Minimum | Typical | Maximum |
|--|---------|--------------|----------|
| Carrier Frequency, MHz. | 417.96 | 418.02 | 418.08 |
| Range (line-of-sight with RFLS-1XT xmtr) | | | ¼ mile |
| Delay from start of transmitter button depression to receiver output (fewer than 4 transmitters transmitting simultaneously) | | 50 msec | 75 msec |
| Delay from start of transmitter button depression to receiver output (more than 3 transmitters transmitting simultaneously) | | 100 msec | 400 msec |
| Battery life, (with LR44 alkaline battery pair) | | 2.5 hrs | |
| Battery life, (with #357 silver-oxide battery pair) | | 4.0 hrs | |
| Battery life, (with single 1/3N lithium battery) | | 7.5 hrs | |
| Low Battery Detect Threshold | | 2.4 V | |
| Battery Input Voltage | 1.6 V | 3 V | 3.5 V |
| Standard e-matches fired in parallel | 2 | | |
| Standard e-matches fired in series | 2 | | |
| Output Fire Voltage, (Armed) | | | 5 V |
| Output Fire Energy, (Armed) | | 0.025 joules | |
| Output Fire Current, (Safe) | | | 0.0 amp |
| Output internal shunt resistance, (Safe) | | | 0.0 ohm |
| Output Continuity Test Current (low duty cycle pulse, once per two seconds) | | 0.9 mA | 1.1 mA |
| Board length, inches | | 1.75 inch | |
| Board width, inches | | 1.75 inch | |
| Height above circuit board, inches | | | 0.5 inch |
| Height below circuit board, inches | | | 0.5 inch |
| Weight (with batteries installed) | | 1.0 oz | |

4.0 OPERATION AND MAINTENANCE.

This section describes the recommended operating procedure and maintenance for the transmitter-receiver system.

4.1 OPERATION.

- 4.1.1** Before connecting the output device, perform a reception test by observing the receiver status indicator while pressing the transmitter buttons. An assistant may be needed for this test. If the receiver location will be fixed, determine the limits of the range in the current environment, and position the transmitter and receiver so that their separation does not exceed $\frac{3}{4}$ of this maximum range. Verify that the receiver and transmitter batteries are not depleted by observing the flashing "STATUS" and "XMTR ENABLED" lights on the receiver and transmitter, respectively. Operation of these indicators is as described in section 1.3 above. Turn the transmitter switch to its "OFF" or "Safe" position, and turn off the receiver.

- 4.1.2** Connect device to receiver output leads as described in section 1.4 above. With the “ARM” switch turned off, turn on the receiver power switch. Check that the “STATUS” indicator is only flashing in bursts of one, two or three to indicate battery level. **If this indicator exhibits continuous or erratic illumination, there is a signal being received which could cause firing when the “ARM” switch is turned on.** Determine the source of the interference before attempting to use the system.
- 4.1.3** When the area around the devices to be actuated is clear of persons who might be injured by an accidental actuation, turn on the receiver’s ARM switch. Verify electrical continuity through the output device by observing a green flashing “STATUS” indicator. If the indicator is flashing red, the output is open or the ARM switch is in “safe” mode, and the receiver will not fire.
- 4.1.4** Turn the transmitter switch to its “ON” or “Enabled” position, and press the appropriate button to actuate the receiver output. A button must be depressed for at least 75 milliseconds to produce a receiver output. The transmitter should avoid proximity to the body and other conductive objects to achieve maximum range and communication reliability.
- 4.1.5** When finished, turn off the receiver ARM and POWER switches, and turn the transmitter switch to its “OFF” or “Safe” position to stop further drain of its batteries. If the receiver and transmitter are to be stored for a prolonged period, remove their batteries as described in section 1.5 above.

You may remove the transmitter antenna to make it easier to store. Be careful not to overtighten the transmitter antenna when screwing it on, as this could cause the mating connector to rotate and break its internal connection. Rotation could also occur, with the same result, when subsequent removal of an overtightened antenna is attempted. The recommended way to install an antenna is to grasp it by its small diameter upper part and rotate gently in a clockwise direction until increased resistance is felt. It need not be tight to achieve a good electrical connection. When removing an antenna for storage, observe the base of the mating connector to ensure that it is not rotating. If the antenna is so tight that rotation is occurring, grasp the hex base of the mating connector with long nose pliers, and then unscrew the antenna.

4.2 MAINTENANCE.

Since there are no calibration or tuning adjustments in the units, the only maintenance required is periodic replacement of the 9 volt battery in the transmitter and the coin batteries in the receivers (if the receivers are not being used in disposable applications). This should be done at least once per year, or at the next opportunity if the battery indicators fail to flash at least 3 times per burst while power is switched on.

The face of the transmitter, which is completely sealed, may be safely cleaned by wiping with a damp cloth if care is taken not to get moisture into the lock switch. The battery compartment door and the junction between the front and back panels are NOT water tight, however. The transmitter must never be immersed in water.

If further information or service is required, contact:

Holatron Systems, LLC.
833 ILANIWAI ST, STE. 2
Honolulu, HI 96813
(808) 372-0956
www.holatron.com