

## Channel Configuration Procedure for High Speed Sequential Controller

Three parameters determine the channel range of the Holatron 12 channel high speed sequential controller:

**Base Channel** (1-12),  
**Last Channel** (1-12),  
**Low Channel** (1-12)

There are 12 cues on each channel. So single channel operation controls 12 cues. Additional cues can be controlled by configuring the transmitter to operate on multiple channels. For example 3 channels would control  $3 \times 12 = 36$  cues, and 12 channels would control  $12 \times 12 = 144$  cues. The controller does this by switching automatically to cue 1 of the next higher channel in its configured range after firing cue 12. When cue 12 of **Last Channel** is fired, the controller switches to cue 1 of **Low Channel**. The controller always starts on cue 1 of **Base Channel** after power-on. Some configuration examples are:

**Base Ch = Last Ch = Low Ch** => Single channel operation.  
**Base Ch = Low Ch = 1, and Last Ch = 2** => Operation on channels 1 & 2.  
**Base Ch = Low Ch = 1, and Last Ch = 6** => Operation on channels 1 through 6.  
**Base Ch = Low Ch = 3, and Last Ch = 5** => Operation on channels 3 through 5.  
**Base Ch = 3, Last Ch = 5, and Low Ch = 2** => Operation on channels 2 through 5, with operation starting on channel 3 after power-on.

### User configures channel range with the following procedure:

1. Remove the rear cover by unscrewing its 4 mounting screws.
2. With the "A" **or** "B" button depressed, turn on the Enable key switch. Then release the button.
3. Enter each channel parameter by setting its number on the controller's digital switch and then momentarily pressing the "A" **and** "B" buttons **simultaneously**.
4. The parameter being entered is indicated by the panel LEDs as: green = Base Ch, Red = Last Ch, green and red = Low Ch.
5. All 3 parameters need not be entered. If only Base Ch is entered, the configuration will be for single channel operation. If only Base Ch and Last Ch are entered, Low Ch will be set = Base Channel.
6. Turn off the key switch when done.
7. Set the digital switch back to the desired automatic fire rate setting, and turn on the key switch.
8. At power-on, the green LED will flash the Base Ch number, and then the red LED will flash the Last Ch number before automatic reset transmission and commencement of normal battery flash mode.
9. Channel configuration is saved in non-volatile memory. So it is not necessary to reconfigure the channel range each time the controller is turned on.
10. Replace the rear cover.